

CE

BOILER GUN

BG38 BOILER GUN OPERATING MANUAL ORIGINAL INSTRUCTIONS



BG38LV model shown

H&S TOOL
A CLIMAX COMPANY

©2023 CLIMAX or its subsidiaries.
All rights reserved.

Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded, or stored in any storage medium, without the express prior written consent of CLIMAX. CLIMAX hereby grants permission to download a single copy of this manual and of any revision hereto onto an electronic storage medium to be viewed and to print one copy of this manual or any revision hereto, provided that such electronic or printed copy of this manual or revision must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is prohibited.

At CLIMAX, we value your opinion.

For comments or questions about this manual or other CLIMAX documentation, please e-mail documentation@cpmt.com.

For comments or questions about CLIMAX products or services, please call CLIMAX or e-mail info@cpmt.com. For quick and accurate service, please provide your representative with the following:

- Your name
- Shipping address
- Telephone number
- Machine model
- Serial number (if applicable)
- Date of purchase

CLIMAX World Headquarters

2712 East 2nd Street
Newberg, Oregon 97132 USA

Telephone (worldwide): +1-503-538-2815
Toll-free (North America): 1-800-333-8311
Fax: 503-538-7600

CLIMAX | H&S Tool (UK Headquarters)

Unit 3 Martel Court
S. Park Business Park
Stockport SK1 2AF, UK

Telephone: +44 (0) 161-406-1720

CLIMAX | H&S Tool (Asia Pacific Headquarters)

316 Tanglin Road #02-01
Singapore 247978

Telephone: +65 9647-2289
Fax: +65 6801-0699

CLIMAX | H&S Tool World Headquarters

715 Weber Dr.
Wadsworth, OH 44281 USA

Telephone: +1-330-336-4550
Fax: 1-330-336-9159
hstool.com

CLIMAX | H&S Tool (European Headquarters)

Am Langen Graben 8
52353 Düren, Germany


Telephone: +49 24-219-1770
E-mail: ClimaxEurope@cpmt.com

CLIMAX | H&S Tool (Middle East Headquarters)

Warehouse #5, Plot: 369 272
Um Sequim Road
Al Quoz 4
PO Box 414 084
Dubai, UAE

Telephone: +971 04-321-0328

CLIMAX GLOBAL LOCATIONS



LIMITED WARRANTY

Climax Portable Machine Tools, Inc. (hereafter referred to as "Climax") warrants that all new machines are free from defects in materials and workmanship. This warranty is available to the original purchaser for a period of one year after delivery. If the original purchaser finds any defect in materials or workmanship within the warranty period, the original purchaser should contact its factory representative and return the entire machine, shipping prepaid, to the factory. Climax will, at its option, either repair or replace the defective machine at no charge and will return the machine with shipping prepaid.

Climax warrants that all parts are free from defects in materials and workmanship, and that all labor has been performed properly. This warranty is available to the customer purchasing parts or labor for a period of 90 days after delivery of the part or repaired machine or 180 days on used machines and components. If the customer purchasing parts or labor finds any defect in materials or workmanship within the warranty period, the purchaser should contact its factory representative and return the part or repaired machine, shipping prepaid, to the factory. Climax will, at its option, either repair or replace the defective part and/ or correct any defect in the labor performed, both at no charge, and return the part or repaired machine shipping prepaid.

These warranties do not apply to the following:

- Damage after the date of shipment not caused by defects in materials or workmanship
- Damage caused by improper or inadequate machine maintenance
- Damage caused by unauthorized machine modification or repair
- Damage caused by machine abuse
- Damage caused by using the machine beyond its rated capacity

All other warranties, express or implied, including without limitation the warranties of merchantability and fitness for a particular purpose are disclaimed and excluded.

Terms of sale

Be sure to review the terms of sale which appear on the reverse side of your invoice. These terms control and limit your rights with respect to the goods purchased from Climax.

About this manual

Climax provides the contents of this manual in good faith as a guideline to the operator. Climax cannot guarantee that the information contained in this manual is correct for applications other than the application described in this manual. Product specifications are subject to change without notice.

This page intentionally left blank

TABLE OF CONTENTS

CHAPTER/SECTION	PAGE
1 INTRODUCTION	1
1.1 HOW TO USE THIS MANUAL	1
1.2 SAFETY ALERTS	1
1.3 GENERAL SAFETY PRECAUTIONS	2
1.4 MACHINE-SPECIFIC SAFETY PRECAUTIONS	3
1.5 RISK ASSESSMENT AND HAZARD MITIGATION	4
1.6 RISK ASSESSMENT CHECKLIST	5
1.7 LABELS	6
1.7.1 Label identification	6
2 OVERVIEW	7
2.1 FEATURES AND COMPONENTS	7
2.2 CONTROLS	8
2.2.1 Pneumatic motor controls	8
2.2.2 Electric motor controls	8
2.3 DIMENSIONS	9
2.4 SPECIFICATIONS	9
2.5 ITEMS REQUIRED BUT NOT SUPPLIED	9
3 SETUP	11
3.1 RECEIPT AND INSPECTION	11
3.2 MACHINE SETUP	12
3.2.1 Wedge locking system	12
3.2.2 Collet locking system	12
3.2.3 Tool holders	13
3.2.4 Center shafts	13
3.3 MACHINE MOUNTING	14
3.4 INSTALLING THE CUTTING TOOLS	15
3.5 MOTORS	16
3.5.1 Pneumatic motor	16
3.5.2 Electric motor	16
4 OPERATION	17
4.1 PRE-OPERATION CHECKS	17
4.2 OPERATION	17
4.2.1 Pneumatic motor	17
4.2.2 Electric motor	18
5 MAINTENANCE	19
5.1 MAINTENANCE CHECKLIST	19

TABLE OF CONTENTS (CONTINUED)

CHAPTER/SECTION	PAGE
5.2 APPROVED LUBRICANTS	19
5.3 MAINTENANCE TASKS	20
5.3.1 Checking and filling the in-line oiler reservoir	20
5.3.2 Servicing the filter element	20
5.3.3 Adjusting the oil flow rate of the in-line oiler	20
5.3.4 Tool holders	21
5.3.5 Greasing the drive and pinion gears	21
5.4 TROUBLESHOOTING	21
5.4.1 The machine isn't turning	21
5.4.2 The machine isn't feeding	21
5.4.3 The machine is performing poorly	21
6 STORAGE AND SHIPPING	23
6.1 STORAGE	23
6.1.1 Short-term storage	23
6.1.2 Long-term storage	23
6.2 SHIPPING	24
6.3 DECOMMISSIONING	24
APPENDIX A ASSEMBLY DRAWINGS	25
APPENDIX B SDS	41

LIST OF FIGURES

FIGURE	PAGE
2-1 BG38 and shipping container	7
2-2 Pneumatic motor throttle lever	8
2-3 Direction and trigger controls	8
2-4 BG38 Boiler Gun dimensions	9
3-1 BG38 Boiler Gun main components	12
3-2 Installed wedge set with extensions	12
3-3 Installed collet set	13
3-4 Changing the center shaft	13
3-5 BG38 Boiler Gun installed in workpiece	14
3-6 Locking rod wrench with speed wheel	14
3-7 Sliding tool holder (l) and fixed tool holder (r)	15
3-8 Cutting bit installed	15
3-9 Universal coupler (top) and quick disconnect (bottom)	16
3-10 Motor direction control set to forward	16
4-1 Hand positioning during boiler gun operation	17
4-2 BG38 with electric motor	18
5-1 In-line oiler sight glass	20
6-1 BG22 shipping container	24
A-1 BG38 boiler gun assembly (P/N 102985)	26
A-2 BG38 boiler gun chart (P/N 102985)	27
A-3 Boiler gun base unit feed wrench assembly (P/N 99969)	28
A-4 BG38 boiler gun high-velocity pneumatic assembly (P/N BG38HV-R)	29
A-5 BG38 boiler gun low-velocity pneumatic assembly (P/N BG38LV-R)	30
A-6 BG38E110-R boiler gun electric assembly (P/N 102987)	31
A-7 BG38CP collet kit assembly (P/N 103077)	32
A-8 BG38 tool holder assembly (P/N 103081)	34
A-9 BG38 tool holder assembly parts list (P/N 103081)	35
A-10 Wedge mount system kit (P/N 103081)	36
A-11 Air hose assembly (P/N HS50509)	38
A-12 Tool kit (P/N 100603)	39

This page intentionally left blank

LIST OF TABLES

TABLE	PAGE
1-1 Sound levels	3
1-2 Risk assessment checklist before set-up	5
1-3 Risk assessment checklist after set-up	5
1-4 BG38 Boiler Gun labels	6
2-1 Sub-component mass	9
5-1 Maintenance intervals and tasks	19
5-2 Approved lubricants	20

This page intentionally left blank

1 INTRODUCTION

IN THIS CHAPTER:

1.1 HOW TO USE THIS MANUAL - - - - - 1

1.2 SAFETY ALERTS - - - - - 1

1.3 GENERAL SAFETY PRECAUTIONS - - - - - 2

1.4 MACHINE-SPECIFIC SAFETY PRECAUTIONS - - - - - 3

1.5 RISK ASSESSMENT AND HAZARD MITIGATION - - - - - 4

1.6 RISK ASSESSMENT CHECKLIST - - - - - 5

1.7 LABELS - - - - - 6

 1.7.1 LABEL IDENTIFICATION - - - - - 6

1.1 HOW TO USE THIS MANUAL

This manual describes information necessary for the setup, operation, maintenance, storage, shipping, and decommissioning of the BG38 Boiler Gun.

Read this entire manual to familiarize yourself with the BG38 Boiler Gun before attempting to set it up or operate it.

The first page of each chapter includes a summary of the chapter contents to help you locate specific information. The appendices contain supplemental product information to aid in setup, operation, and maintenance tasks.

1.2 SAFETY ALERTS

Pay careful attention to the safety alerts printed throughout this manual. Safety alerts will call your attention to specific hazardous situations that may be encountered when operating this machine.

Examples of safety alerts used in this manual are defined here¹:

! DANGER

indicates a hazardous situation which, if not avoided, **WILL** result in death or severe injury.

! WARNING

indicates a hazardous situation which, if not avoided, **COULD** result in death or severe injury.

! CAUTION

indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

indicates a hazardous situation which, if not avoided, could result in property damage, equipment failure, or undesired work results

1. For more information on safety alerts, refer to *ANSI/NEMA Z535.6-2011, Product safety Information in Product Manuals, Instructions, and Other Collateral Materials.*

1.3 GENERAL SAFETY PRECAUTIONS

H&S leads the way in promoting the safe use of portable machine tools. Safety is a joint effort. You, the end user, must do your part by being aware of your work environment and closely following the operating procedures and safety precautions contained in this manual, as well as your employer's safety guidelines.

Observe the following safety precautions when operating or working around the machine.

Training - Before operating this or any machine tool, you should receive instruction from a qualified trainer. Contact H&S for machine-specific training information.

Risk assessment - Working with and around this machine poses risks to your safety. You, the end user, are responsible for conducting a risk assessment of each job site before setting up and operating this machine.

Intended use - Use this machine in accordance with the instructions and precautions in this manual. Do not use this machine for any purpose other than its intended use as described in this manual.

Personal protective equipment - Always wear appropriate personal protective gear when operating this or any other machine tool. Flame-resistant clothing with long sleeves and legs is recommended when operating the machine. Hot chips from the workpiece may burn or cut bare skin.

Work area - Keep the work area around the machine clear of clutter. Restrain cords and hoses connected to the machine. Keep other cords and hoses away from the work area.

Lifting - Many H&S machine components are very heavy. Whenever possible, lift the machine or its components using proper hoisting equipment and rigging. Always use designated lifting points on the machine. Follow lifting instructions in the setup procedures of this manual.

Lock-out/tag-out - Lock-out and tag-out the machine before performing maintenance.

Moving parts - H&S machines have numerous exposed moving parts and interfaces that can

cause severe impact, pinching, cutting, and other injuries. Except for stationary operating controls, avoid contact with moving parts by hands or tools during machine operation. Remove gloves and secure hair, clothing, jewelry, and pocket items to prevent them from becoming entangled in moving parts.

Sharp edges - Cutting tools and workpieces have sharp edges that can easily cut skin. Wear protective gloves and exercise caution when handling a cutting tool or workpiece.

Hot surfaces - During operation, motors, pumps, HPUs, and cutting tools can generate enough heat to cause severe burns. Pay attention to hot surface labels, and avoid contact with bare skin until the machine has cooled.

1.4 MACHINE-SPECIFIC SAFETY PRECAUTIONS

Eye hazard - This machine produces metal chips during operation. Always wear eye protection when operating the machine.

Hazardous environments - Do not operate the machine in environments where potentially explosive materials, toxic chemicals, or radiation may be present.

Sound level - This machine produces potentially harmful sound levels. Hearing protection is required when operating this machine or working around it. During testing, the machine produced the sound levels¹ listed in Table 1-1.

TABLE 1-1. SOUND LEVELS

	Pneumatic Motor
Average sound pressure	90.6 dBA
Operator sound pressure	91.5 dBA
Bystander sound pressure	89.4 dBA
	Electric Motor
Average sound pressure	85 dBA
Operator sound pressure	85 dBA
Bystander sound pressure	85 dBA

1. Machine sound testing was conducted in accordance with European Harmonized Standards EN ISO 3744:2010 and EN 11201:2010.

1.5 RISK ASSESSMENT AND HAZARD MITIGATION

Machine Tools are specifically designed to perform precise material-removal operations.

Stationary Machine Tools include lathes and milling machines and are typically found in a machine shop. They are mounted in a fixed location during operation and are considered to be a complete, self-contained machine. Stationary Machine Tools achieve the rigidity needed to accomplish material-removal operations from the structure that is an integral part of the machine tool.

In contrast, Portable Machine Tools are designed for on-site machining applications. They typically attach directly to the workpiece itself, or to an adjacent structure, and achieve their rigidity from the structure to which it is attached. The design intent is that the Portable Machine Tool and the structure to which it is attached become one complete machine during the material-removal process.

To achieve the intended results and to promote safety, the operator must understand and follow the design intent, set-up, and operation practices that are unique to Portable Machine Tools valve testers.

The operator must perform an overall review and on-site risk assessment of the intended application. Due to the unique nature of portable machining applications hydrostatic testing, identifying one or more hazards that must be addressed is typical.

When performing the on-site risk assessment, it is important to consider the Portable Machine Tool valve tester and the workpiece as a whole.

1.6 RISK ASSESSMENT CHECKLIST

The following checklist is not intended to be an all inclusive list of things to watch out for when setting up and operating this Portable Machine Tool.

However, these checklists are typical of the types of risks the assembler and operator should consider. Use these checklists as part of your risk assessment:

TABLE 1-2. RISK ASSESSMENT CHECKLIST BEFORE SET-UP

Before set-up	
<input type="checkbox"/>	I took note of all the warning labels on the machine.
<input type="checkbox"/>	I removed or mitigated all identified risks (such as tripping, cutting, crushing, entanglement, shearing, or falling objects).
<input type="checkbox"/>	I considered the need for personnel safety guarding and installed any necessary guards.
<input type="checkbox"/>	I read the machine setup instructions (Section 3.2) and took inventory of all the items required but not supplied (Section 2.5).
<input type="checkbox"/>	I considered how this machine operates and identified the best placement for the controls, cabling, and the operator.
<input type="checkbox"/>	I evaluated and mitigated any other potential risks specific to my work area.

TABLE 1-3. RISK ASSESSMENT CHECKLIST AFTER SET-UP







After set-up	
<input type="checkbox"/>	I checked that the machine is safely installed (according to Section 3) and the potential fall path is clear. If the machine is installed at an elevated position, I checked that the machine is safeguarded against falling.
<input type="checkbox"/>	I identified all possible pinch points, such as those caused by rotating parts, and informed the affected personnel.
<input type="checkbox"/>	I planned for containment of any chips or swarf produced by the machine.
<input type="checkbox"/>	I followed the required Maintenance Intervals (Section 5.1) with the recommended lubricants (Section 5.2).
<input type="checkbox"/>	I checked that all affected personnel have the recommended personal protective equipment, as well as any site-required or regulatory equipment.
<input type="checkbox"/>	I checked that all affected personnel understand and are clear of the danger zone.
<input type="checkbox"/>	I evaluated and mitigated any other potential risks specific to my work area.

1.7 LABELS

1.7.1 Label identification

The following warning labels should be on your machine. If any are defaced or missing, contact H&S Tool immediately for replacements.

TABLE 1-4. BG38 BOILER GUN LABELS

	<p>P/N 100206 BG38-HV label</p> <p>P/N 100207 BG38-LV label</p> <p>P/N 100251 BG38-E label</p>		<p>P/N 100199 H&S company label</p>
	<p>P/N 35828 CE serial number plate</p>		<p>P/N 100239 BG38 container label</p>
	<p>PN 87271 Warning label: use eye and ear protection, and read the operating manual</p>		<p>P/N 100240 Wedge and pad chart</p>

H&S TOOL WEDGE AND PAD CHART			
MACHINE MODEL	CENTERSHAFT INCHES - MM	WEDGE SIZE	Ø RANGE INCHES - MM
BG38 BG38LV BG38HV BG38PLUS	8.625 (15.6)	B-01	0.625 - 0.810 (15.9 - 20.6)
		B-02	0.750 - 0.935 (19.1 - 23.7)
		B-03	0.875 - 1.060 (22.2 - 26.9)
		B-04	1.000 - 1.185 (25.4 - 30.1)
		B-05	1.125 - 1.310 (28.6 - 33.2)
		B-06	1.250 - 1.435 (31.7 - 36.4)
		B-07	1.375 - 1.560 (34.9 - 39.6)
		B-08	1.500 - 1.685 (38.1 - 42.7)
		B-09	1.625 - 1.810 (41.2 - 45.9)
		B-10	1.750 - 1.935 (44.4 - 49.1)
		B-11 + B-04	1.875 - 2.060 (47.6 - 52.3)
		B-12 + B-04	2.000 - 2.185 (50.8 - 55.5)
		B-13 + B-04	2.125 - 2.310 (53.9 - 58.6)
		B-14 + B-04	2.250 - 2.435 (57.1 - 61.8)
BG38LV BG38HV BG38PLUS	8.625 (15.6)	B-15 + B-04	2.375 - 2.560 (60.3 - 65.0)
		B-16 + B-04	2.500 - 2.685 (63.5 - 68.2)
		B-17 + B-04	2.625 - 2.810 (66.6 - 71.3)
		B-18 + B-04	2.750 - 2.935 (69.8 - 74.5)
		B-19 + B-04	2.875 - 3.060 (73.0 - 77.7)

H&S TOOL 718 Weber Dr. Westborough, OH 42891
PH: 330.338.4500 / FAX: 330.338.9159
WEBSITE: HSTOOL.COM

2 OVERVIEW

IN THIS CHAPTER:

2.1 FEATURES AND COMPONENTS - - - - - 7

2.2 CONTROLS - - - - - 8

 2.2.1 PNEUMATIC MOTOR CONTROLS - - - - - 8

 2.2.2 ELECTRIC MOTOR CONTROLS - - - - - 8

2.3 DIMENSIONS - - - - - 9

2.4 SPECIFICATIONS - - - - - 9

2.5 ITEMS REQUIRED BUT NOT SUPPLIED - - - - - 9

2.1 FEATURES AND COMPONENTS

The BG38 Boiler Gun is a portable, gear-driven, inside-diameter (ID)-mounted, single or dual-point beveling and facing machine for use on workpieces with a range of .625" (12.7mm) ID to 3.00" (63.5mm) OD.

Principle components include the following:

Drive options: Available with either a 1.3 HP pneumatic motor or a 1 HP electric motor.

High Velocity (HV) and Low Velocity (LV) -HV delivers higher cutting speeds to turn specialty carbide inserts. LV is geared for heavy walls and hard alloys.

Mounting systems—Either a wedge or collet mounting system secures the BG38 Boiler Gun to the workpiece. They are both self-centering and adapt to a wide range of pipe sizes.

Tool holders—Available with sliding tools holders, in multiple sizes.

Torque free operation—Once securely mounted the BG38 Boiler Gun requires no additional effort to operate aside from feeding the cutting tool.

Wrench feed—Advances the cutting tools in confined areas with a ratcheting system. This system has a smaller footprint.

Speed wheel—Provides a quicker way to advance the locking rod nut before fully tightening with the wrench in confined spaces.



FIGURE 2-1. BG38 AND SHIPPING CONTAINER

2.2 CONTROLS

Depending on the users requirements, the BG38 Boiler Gun can be powered by either a pneumatic or electric motor. The controls for each type of motor follow.

⚠ WARNING

Always stop the machine and disconnect any power supply before making adjustments to controls or machine components. Failure to follow this safety precaution may result in severe injury.

2.2.1 Pneumatic motor controls

The pneumatic motor used on the BG38 Boiler Gun features a throttle lever. The safety lock must be disengaged by pressing and holding up while depressing the throttle lever. The throttle lever actuates the motor; when released, the motor will stop and the safety lock will re-engage.

This is an on or off control only.



FIGURE 2-2. PNEUMATIC MOTOR THROTTLE LEVER

2.2.2 Electric motor controls

The electric motor controls are similar to a drill or drill driver. The trigger is squeezed to actuate the motor, when released the motor will stop.



FIGURE 2-3. DIRECTION AND TRIGGER CONTROLS

This speed is controlled by how far the trigger is pulled in or let out.

The electric motor also has a direction control, which in this application is not used. The direction control should always be set to forward.

2.3 DIMENSIONS

Figure 2-4 shows the machine and operating dimensions.




FIGURE 2-4. BG38 BOILER GUN DIMENSIONS

2.4 SPECIFICATIONS

TABLE 2-1. SUB-COMPONENT MASS

P/N	Component	Mass in lbs (kg)
BG38	BG38 Boiler Gun Pneumatic	17 (7.7)
BG38E	BG38 Boiler Gun Electric	14 (6.3)

2.5 ITEMS REQUIRED BUT NOT SUPPLIED

The following items may be required but not supplied in your H&S product kit:

- Tape measure or steel ruler
- Rubber mallet
- Pliers

This page intentionally left blank

3 SETUP

IN THIS CHAPTER:

3.1 RECEIPT AND INSPECTION - - - - -11

3.2 MACHINE SETUP - - - - -12

 3.2.1 WEDGE LOCKING SYSTEM - - - - -12

 3.2.2 COLLET LOCKING SYSTEM - - - - -12

 3.2.3 TOOL HOLDERS - - - - -13

 3.2.4 CENTER SHAFTS - - - - -13

3.3 MACHINE MOUNTING - - - - -14

3.4 INSTALLING THE CUTTING TOOLS - - - - -15

3.5 MOTORS - - - - -16

 3.5.1 PNEUMATIC MOTOR - - - - -16

 3.5.2 ELECTRIC MOTOR - - - - -16

This section describes the setup procedures for the BG38 Boiler Gun.

3.1 RECEIPT AND INSPECTION

Your H&S product was inspected and tested prior to shipment then packaged for normal shipment conditions. H&S does not guarantee the condition of your machine upon delivery.

When you receive your H&S product, perform the following receipt checks:

1. Inspect the shipping containers for damage.
2. Check the contents of the shipping containers against the included invoice to make sure that all components have been shipped.

3. Inspect all components for damage.

Contact H&S immediately to report damaged or missing components.

NOTICE

Keep the shipping container and all packing materials for future storage and shipping of the machine.

3.2 MACHINE SETUP




FIGURE 3-1. BG38 BOILER GUN MAIN COMPONENTS

Do the following to setup the BG38 Boiler Gun:

3.2.1 Wedge locking system

1. Complete the risk assessment checklist in Table 1-2 on page 5.
2. Position the machine on a solid support for installation of the wedge set.
3. Measure the ID of the pipe to be machined. Use the chart on the inside lid of the shipping container to determine the size of the base wedge, extension set and locking rod.
4. Install the locking rod from the front of the machine, sliding it through the center shaft.
5. Install the speed wheel/rod wrench on the end of the locking rod and install the lock nut.
6. Slide the base wedge set over the end plate by expanding the springs or band spring.
7. Seat the base wedges in the end plate and align the base wedges with the slots in the center shaft.

8. If installing wedge extensions, secure three of the same size range onto the base wedges with the screws.




FIGURE 3-2. INSTALLED WEDGE SET WITH EXTENSIONS

3.2.2 Collet locking system

1. Complete the risk assessment checklist in Table 1-2 on page 5.
2. Position the machine on a solid support for installation of the collet set.
3. Measure the ID of the pipe to be machined and determine the size of the collet set to be used.

4. Slide a locking rod into the center shaft from the rear of the machine.
5. Thread the required collet set on the end of the locking rod until the collets begin to engage the center shaft.
6. Insert a cotter pin through the hole in the locking rod and open the splines to secure.
7. If not present, install the locking rod wrench and secure with the retaining clips.



FIGURE 3-3. INSTALLED COLLET SET

3.2.3 Tool holders

The BG38 Boiler Gun can be used with tool holders in different sizes and types.

Do the following to switch between tool holders:

To remove:

1. Loosen the set screw in the body of the tool holder.
2. The tool holder has an interference fit with the main gear. Strike the back face of the tool holder to remove it towards the front of the machine.
3. The shaft key may come loose from the main gear during removal. Retain it for reuse.

To install:

1. Check that the set screw in the body of the tool holder is backed out or remove it completely.
2. Install the shaft key in the key slot on the main gear.
3. Slide the tool holder onto the main gear, aligning the key way with the shaft key.

4. Tap into place until seated against the shoulder on the main gear.
5. Reinstall or tighten the set screw in the tool holder body until secure.

3.2.4 Center shafts

Depending on the application, the center shaft may need switched out to offer a different size range or locking system.

Do the following to switch out center shafts:

1. Position the machine on a solid support to change the center shafts.
2. Remove the locking rod, rod wrench and wedge or collet locking sets.
3. Remove the three screws in the retaining plate and lift the retaining plate from the machine body. Be aware of the thrust bearing parts during disassembly.
4. Remove the feed nut from the center shaft.
5. The center shaft can now be removed through the front of the machine.
6. Install the other center shaft from the front of the machine threads first.
7. Replace the thrust bearing parts being mindful of the order and orientation.
8. Thread the feed nut onto the center shaft until the center shaft is flush with the back of the feed nut.
9. Reinstall the retaining plate and secure with the two screws.



FIGURE 3-4. CHANGING THE CENTER SHAFT

3.3 MACHINE MOUNTING

Do the following to mount the BG38 Boiler Gun on the workpiece:

1. Insert the mounting system end of the BG38 Boiler Gun into the workpiece until there is approximately .50" (12.7mm) between the end of the mounting system and the face of the workpiece. This will allow for enough material for removal to complete most procedures.




FIGURE 3-5. BG38 BOILER GUN INSTALLED IN WORKPIECE

2. Tighten the mounting system by turning the lock rod clock-wise using either the rod wrench or the speed wheel. Once snug, verify that the mounting system position in the workpiece has been maintained. Completely tighten the mounting system using the locking rod wrench.




FIGURE 3-6. LOCKING ROD WRENCH WITH SPEED WHEEL

⚠ WARNING

Check that the mounting system has been fully tightened. After the machine has made 2-3 revolutions during operation, recheck the mounting system for tightness in the workpiece. If loose, the machine itself could rotate causing severe injury to the operator.

3.4 INSTALLING THE CUTTING TOOLS




FIGURE 3-7. SLIDING TOOL HOLDER (L) AND FIXED TOOL HOLDER (R)

Do the following to install the cutting bit(s):

1. Advance the tool holder towards the workpiece to help with alignment of the cutting bit(s).
2. Loosen the set screws in the blade locks.
3. Slide the cutting bit into the channel with the beveled cutting edge facing the direction of rotation.
4. Align the cutting edge of the tool to cut the full width of the workpiece wall (sliding tool holder only).
5. Tighten the set screw(s) to secure the cutting bit(s) to the tool holder.

TIP:

While the BG38 Boiler Gun can be operated with one blade, smoother operation on harder materials or thicker pipe walls will result with the use of two blades.




FIGURE 3-8. CUTTING BIT INSTALLED

3.5 MOTORS

The BG38 Boiler Gun is powered by either a pneumatic motor or an electric motor. The following subsections explain how to set up each for operation.

3.5.1 Pneumatic motor

Do the following to prepare the pneumatic motor for use (See Section 2.2 for controls):

1. Connect the air supply line to the in-line oiler/filter end of the air hose assembly with the universal coupler. Secure with the lock pin.
2. Connect the air hose assembly to the pneumatic drive motor using the quick disconnect coupler.



FIGURE 3-9. UNIVERSAL COUPLER (TOP) AND QUICK DISCONNECT (BOTTOM)

3.5.2 Electric motor

Do the following to prepare the electric motor for use (See Section 2.2 for controls):

1. Verify that the direction selector is set to forward.



FIGURE 3-10. MOTOR DIRECTION CONTROL SET TO FORWARD

2. Plug the drive into an OSHA certified power source or consult a licensed electrician for additional power supply options.

4 OPERATION

IN THIS CHAPTER:

4.1 PRE-OPERATION CHECKS - - - - -17
 4.2 OPERATION - - - - -17
 4.2.1 PNEUMATIC MOTOR - - - - -17
 4.2.2 ELECTRIC MOTOR - - - - -18

4.1 PRE-OPERATION CHECKS

Do the following checks before operating the machine:

1. Complete the risk assessment checklist in Table 1-3 on page 5.
2. Check that the work area is clear of non-essential personnel and equipment.
3. Check that the machine control/observation area will not be in the path of hot flying chips during machine operation.
4. Check the machine is securely mounted to the workpiece, according to Section 3.3 on page 14.
5. Check that hoses and electric cords are routed and secured to avoid tripping, entanglement, damage from hot chips, or other damage should an air hose or connection fail.
6. Check the cutting tool condition and sharpness.
7. On the in-line air lubricator, verify that oil is present in the sight glass. (See Section 5.3.1)
8. Check that all hand tools are removed from inside the machine and the work area.

4.2 OPERATION

The BG38 Boiler Gun can machine both OD and ID bevels and face or shorten pipes. Aside from the use of different blades, operation is the same for all the machining processes. See Section 2.2 for controls information.

4.2.1 Pneumatic motor

To operate the BG38 Boiler Gun with the pneumatic motor do the following:

1. Actuate the motor by unlocking the safety lock then squeeze and hold the throttle lever.
2. With the other hand turn the feed wrench to advance the cutting tool into the workpiece.
3. Continue to turn the feed wrench until the required machining is complete. Base the feed rate on the motor's feedback, if the RPMs drop or the machine stalls slow the feed rate.
4. Once complete, allow the machine to make a few revolutions without feeding the cutting tool to clean up the machined surface.

5. Release the throttle lever to stop the machine.



FIGURE 4-1. HAND POSITIONING DURING BOILER GUN OPERATION

6. Reverse the rotation of the feed wrench 2-3 revolutions to back the cutting tool away from the workpiece. This also resets the travel of the machine for the next workpiece.
7. To remove the BG38 Boiler Gun from the workpiece do the following:

- a) Turn off the air supply at the source. Disconnect the air hose assembly from the machine.
- b) Turn the locking wrench to loosen the locking system from the workpiece.
- c) Slide the BG38 Boiler Gun straight out from the workpiece using the body of the machine to support its weight.

5. Release the trigger to stop the machine.



FIGURE 4-2. BG38 WITH ELECTRIC MOTOR

6. Reverse the rotation on the feed wrench 2-3 revolutions to back the cutting tool away from the workpiece.
7. To remove the BG38 Boiler Gun from the workpiece do the following:
 - a) Unplug or disconnect the power supply from drive motor. Lock out/tag out where applicable.
 - b) Turn the locking wrench to loosen the locking system from the workpiece.
 - c) Slide the BG38 Boiler Gun straight out from the workpiece using the body of the machine to support its weight.

⚠ WARNING

Always pick up and move the BG38 Boiler Gun by body of the machine. Never pick up the BG38 Boiler Gun by the throttle lever section of the air motor, actuation of the motor could occur and lead to severe injury. Never pick up the BG38 Boiler Gun by the air hose assembly as it could become detached and result in injury or damage to the machine. Do not pick up and move the machine by either of the wrenches as damage to the machine could occur.

4.2.2 Electric motor

To operate the BG38 Boiler Gun with the electric motor do the following:

1. Start the motor by squeezing and holding the trigger.
2. With the other hand turn the feed wrench to advance the cutting tool into the workpiece.
3. Continue to turn the feed wrench until the required machining is complete. Base the feed rate on the machine's feedback, if the RPMs drop or the motor stalls slow the feed rate.
4. Once complete, allow the machine to make a few revolutions without feeding the cutting tool to clean up the machined surface.

⚠ WARNING

Always pick up and move the BG38 Boiler Gun using the body of the machine or combination of the center shaft and machine body. Never pick up the BG38 Boiler Gun by the handle section of the electric driver, actuation of the motor could occur and lead to severe injury. Never pick up the BG38 Boiler Gun by electrical cord as it could result in damage to the machine. Do not pick up and move the machine by the feed wrench as damage to the machine could occur.

5 MAINTENANCE

IN THIS CHAPTER:

5.1 MAINTENANCE CHECKLIST - - - - -19

5.2 APPROVED LUBRICANTS - - - - -19

5.3 MAINTENANCE TASKS - - - - -20

 5.3.1 CHECKING AND FILLING THE IN-LINE OILER RESERVOIR - - - - -20

 5.3.2 SERVICING THE FILTER ELEMENT - - - - -20

 5.3.3 ADJUSTING THE OIL FLOW RATE OF THE IN-LINE OILER - - - - -20

 5.3.4 TOOL HOLDERS - - - - -21

 5.3.5 GREASING THE DRIVE AND PINION GEARS - - - - -21

5.4 TROUBLESHOOTING - - - - -21

 5.4.1 THE MACHINE ISN'T TURNING - - - - -21

 5.4.2 THE MACHINE ISN'T FEEDING - - - - -21

 5.4.3 THE MACHINE IS PERFORMING POORLY - - - - -21

5.1 MAINTENANCE CHECKLIST

Table 5-1 lists maintenance intervals and tasks

TABLE 5-1. MAINTENANCE INTERVALS AND TASKS

Interval	Task	Reference
Before each use	Check that oil is present in the sight glass on the in-line oiler, refill as needed.	5.3.1
	Check air lines for damage and wear.	--
	Check the cutting tool for sharpness. Replace as necessary.	--
Before and after each use	Remove debris, oil, and moisture from machine surfaces.	--
Every ten operation cycles	Lubricate center shaft threads.	--
	Adjustment of the oil flow rate.	5.3.3
	Filter element service.	5.3.2

5.2 APPROVED LUBRICANTS

H&S recommends using the following lubricants at the locations indicated.

Failure to use the appropriate lubricants can result in damage and premature machine wear.

CAUTION

Avoid damage, premature machine wear, and protect your warranty by using only approved lubricants.

TABLE 5-2. APPROVED LUBRICANTS

Application Area	Lubricant	Biodegradable Lubricant	Viscosity (cSt)	Quantity	Frequency
Threads of the center shaft	WD-40 or light-weight spray lube	N/A		Light coating applied by spray	Daily during machine use
In-line oiler	MOBIL ALMO 525 or 10W SAE oil	N/A	46 @ 40C	Fill oil lubricator body	Each use
Unpainted Surfaces	LPS1 or LPS2	N/A	38 @ 25C	As required	Each use, and before storage
Drive and pinion gears	NOOK PAG-1 grease	N/A	113 @ 100C	Light coating applied by hand	Weekly during machine use

5.3 MAINTENANCE TASKS

Maintenance tasks are described in the following sections.

5.3.1 Checking and filling the in-line oiler reservoir

Do the following to check and fill the in-line oiler:

1. Check sight glass on the oil reservoir for the presence of oil.
2. To refill: Remove the cap, fill the reservoir and replace the cap.



FIGURE 5-1. IN-LINE OILER SIGHT GLASS

5.3.2 Servicing the filter element

See Figure A-11 on page 38.

Do the following to service the filter element:

1. Remove the filter nut to access the filter element.
2. Slide the filter element out of the filter housing.
3. Clean the filter element with a solvent and compressed air.
4. Reassemble the filter and replace the filter nut.

5.3.3 Adjusting the oil flow rate of the in-line oiler

WARNING

To adjust the oil flow rate the machine must be mounted as if being used. ALL operating and safety precautions must be taken to avoid injuries.

Different lubricants and environments may effect the rate of the in-line oiler.

Do the following to adjust the oil flow rate:

1. Remove the cap and check the oil level. Refill as needed.

2. Set the oiler valve to '3' as a baseline for the flow rate.
3. Replace the cap.
4. Mount and setup the machine (see Section 3.2-3.5)
5. Squeeze and hold the throttle lever to run the machine.
6. Hold a sheet of white paper approximately 4" (101mm) in front of the exhaust ports on the pneumatic motor. If adjusted correctly, there will be a light splatter of oil on the paper after a few seconds of operation.
7. If the oil rate needs adjusted, disconnect the air supply line from the air filter end of the air hose assembly.
8. Repeat Step 1.
9. The larger the number on the oiler valve the higher the oil flow rate. Adjust as required.
10. Replace the cap and retest the machine for corrected oil flow rate.

5.3.4 Tool holders

Do the following to service the tool holders:

1. Monitor and replace as necessary, the o-rings on the ID of the tool holder.
2. Monitor and replace as necessary, the key stock between the main gear and the tool holders.

5.3.5 Greasing the drive and pinion gears

Do the following to grease the drive and pinion gears:

1. On either drive type, remove the four screws in the gearbox adapter.
2. Slide the entire motor, gearbox and gearbox adapter out of the machine housing.
3. Both the drive and pinions gears are now accessible to be greased.
4. Reverse steps 1 and 2 to reassemble.

5.4 TROUBLESHOOTING

This section is intended to help you solve basic machine performance problems. For serious maintenance or if you have questions on the following procedures, contact H&S.

5.4.1 The machine isn't turning

If the machine is not rotating, check the following:

1. The air supply line is connected and sufficient air pressure is present (pneumatic motor only).
2. The power source is connected and energized (electric motor only).

5.4.2 The machine isn't feeding

If the machine isn't feeding properly, check the following:

1. The center shaft is properly installed in the machine and .50" (12.7mm) projects through the back of the feed wrench.
2. The feed wrench is being turned in the wrong direction.

3. The center shaft has been fed too far into the machine and needs retracted so .50" (12.7mm) projects through the back of the feed wrench.

5.4.3 The machine is performing poorly

If the machine is performing poorly, check the following:

1. The cutting tool is installed correctly.
2. That the set screw on the tool holder is tight to the center shaft.
3. The machine is tight to the workpiece.
4. The cutting tool or insert is sharp and has the correct geometry for the material and type of cut.
5. For the electric motors: The feed direction is set to forward.
6. Pneumatic motor:
 - a) There is oil in the in-line oiler.
 - b) The air supply to the machine is sufficient in both quantity and pressure. Optimal levels are: 90PSI at 38CFM.

This page intentionally left blank

6 STORAGE AND SHIPPING

IN THIS CHAPTER:

6.1 STORAGE	-23
6.1.1 SHORT-TERM STORAGE	-23
6.1.2 LONG-TERM STORAGE	-23
6.2 SHIPPING	-24
6.3 DECOMMISSIONING	-24

6.1 STORAGE

Proper storage of the BG38 Boiler Gun will extend its usefulness and prevent undue damage.

Store the BG38 Boiler Gun in its original shipping container. Keep all packing materials for repackaging the machine (see Figure 6-1).

6.1.1 Short-term storage

Do the following for short-term storage (three months or less):

1. Remove the tooling.
2. Remove hoses.
3. Clean the machine to remove dirt, grease, metal chips, and moisture.
4. Drain all liquids from the in-line pneumatic oiler.

5. Spray all unpainted surfaces with LPS-2 to prevent corrosion.
6. Store the BG38 Boiler Gun in its original shipping container (see Figure 6-1).

6.1.2 Long-term storage

Do the following for long-term storage (longer than three months):

1. Follow the short-term storage instructions, but use LPS-3 instead of LPS-2.
2. Add a desiccant pouch to the shipping container. Replace according to manufacturer instructions.
3. Store the shipping container in an environment out of direct sunlight with temperature < 70°F (21°C) and humidity < 50%.

6.2 SHIPPING

The BG38 Boiler Gun can be reshipped in its original shipping container, as shown in Figure 6-1.




FIGURE 6-1. BG22 SHIPPING CONTAINER


6.3 DECOMMISSIONING

To decommission the BG38 Boiler Gun prior to disposal, remove the drive motor and dispose of it separately from the rest of the machine components. Refer to Appendix A for component assembly information.

APPENDIX A ASSEMBLY DRAWINGS

Drawing list

FIGURE A-1. BG38 BOILER GUN ASSEMBLY (P/N 102985) - - - - -	-26
FIGURE A-2. BG38 BOILER GUN CHART (P/N 102985) - - - - -	-27
FIGURE A-3. BOILER GUN BASE UNIT FEED WRENCH ASSEMBLY (P/N 99969) - - - - -	-28
FIGURE A-4. BG38 BOILER GUN HIGH-VELOCITY PNEUMATIC ASSEMBLY (P/N BG38HV-R) - - - - -	-29
FIGURE A-5. BG38 BOILER GUN LOW-VELOCITY PNEUMATIC ASSEMBLY (P/N BG38LV-R) - - - - -	-30
FIGURE A-6. BG38E110-R BOILER GUN ELECTRIC ASSEMBLY (P/N 102987) - - - - -	-31
FIGURE A-7. BG38CP COLLET KIT ASSEMBLY (P/N 103077) - - - - -	-32
FIGURE A-8. BG38 TOOL HOLDER ASSEMBLY (P/N 103081) - - - - -	-34
FIGURE A-9. BG38 TOOL HOLDER ASSEMBLY PARTS LIST (P/N 103081) - - - - -	-35
FIGURE A-10. WEDGE MOUNT SYSTEM KIT (P/N 103081) - - - - -	-36
FIGURE A-11. AIR HOSE ASSEMBLY (P/N HS50509) - - - - -	-37
FIGURE A-12. TOOL KIT (P/N 100603) - - - - -	-38




PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	SEE CHART	(NOT SHOWN) CHART TOOLKIT
2	1	SEE CHART	CHART MOUNTING SYSTEM
3	1	SEE CHART	CHART BG38 BOILER GUN
4	1	SEE CHART	CHART KIT TOOL HOLDER BG38
5	6	SEE CHART	CHART KIT TOOL BITS BG38

FIGURE A-1. BG38 BOILER GUN ASSEMBLY (P/N 102985)


AVAILABLE CONFIGURATIONS						
PART NO.	DESCRIPTION	ITEM 1	ITEM 2	ITEM 3	ITEM 4	ITEM 5
BG38HV/K-R	MODEL BG38 BOILER GUN HIGH VELOCITY PNEU 140RPM WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38HV-R	98231	BLS37
BG38LV/K-R	MODEL BG38 BOILER GUN LOW VELOCITY PNEU 90RPM WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38LV-R	98231	BLS37
BG38PLK-R	MODEL BG38 BOILER GUN PLUS PNEU 200RPM WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38PL-R	98231	BLS37
BG38E110K-R	MODEL BG38 BOILER GUN ELEC 120V 1HP WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38E110-R	98231	BLS37
BG38E220K-R	MODEL BG38 BOILER GUN ELEC 220V 0.75KW WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38E220-R	98231	BLS37
BG38C110K-R	MODEL BG38 BOILER GUN CORDLESS ELEC 120V 1HP WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38C110-R	98231	BLS37
BG38C220K-R	MODEL BG38 BOILER GUN CORDLESS ELEC 220V 0.75KW WRENCH FEED FULL RANGE WEDGE SYSTEM	100603	BG38WSET	BG38C220-R	98231	BLS37

FIGURE A-2. BG38 BOILER GUN CHART (P/N 102985)




PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	911-0005	KEY 3/16 RADIUS ONE SIDE X 5/8 SQ BOTH ENDS
2	1	10534	RING SNAP 1 OD
3	4	10588	SCREW DRIVE #2 x 1/4 HOLE SIZE .089
4	3	23361	SCREW 10-24 X 3/8 BHSCS
5	3	26395	SCREW 10-24 X 5/8 FHSCS
6	1	35828	PLATE SERIAL YEAR MODEL CE 1.5 X 2.0
7	1	87271	(NOT SHOWN) LABEL WARNING - EYE EAR MANUAL PROTECTION 1-3/8 X 2-3/4
8	1	94883	BEARING THRUST MODIFIED 31MM X 47MM X 11MM
9	1	100199	LABEL H&S LOGO 1.875 X 1.000
10	1	100817	O-RING 3/32 X 1-3/16 ID X 1-3/8 OD 70 DURO
11	2	102925	BRG NEEDLE 5/8 ID X 7/8 OD X 0.750 OPEN
12	1	104340	BRG THRUST MODIFIED 17.65MM ID X 30MM OD X 9MM H
13	1	23081119900	WRENCH 5/8" HEX
14	1	23259119900	WRENCH 7/8" HEX
15	1	B001910	NEEDLE BEARING 1.188 ID X 1.500 OD X .625 W
16	3	B002519	WASHER SPRING WAVE .901 ID X 1.159 OD X .013 THICK
17	1	B002522	HOUSING BG38
18	1	B002524	GEAR BEVEL 18 TOOTH 10 PITCH 20 DEG FORM CUSTOM
19	1	B002525	CENTERSHAFT LOCK
20	1	B002526	FEEDNUT
21	1	B002527	RETAINER PLATE
25	2	96020	SHIM 35MM ID X 45MM OD X .1MM TH SPRING STEEL
26	1	96043	SHIM 35MM ID X 45MM OD X .2MM TH SPRING STEEL
27	1	96051	SHIM 35MM ID X 45MM OD X .3MM TH SPRING STEEL

FIGURE A-3. BOILER GUN BASE UNIT FEED WRENCH ASSEMBLY (P/N 99969)



PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	911-0011	KEY 3/16 RADIUS ONE SIDE X 3/4 SQ BOTH ENDS
2	1	11731	SCREW 5/16-18 X 1 SSSHDP
3	1	98855	SWIVEL DOUBLE AIR 1/2 NPTM X 1/2 NPTF
4	1	99969	NFIS BASE UNIT BG38 BOILER GUN TUBE BEVELER WRENCH FEED
5	1	100206	(NOT SHOWN) LABEL BG38HV METALLIC
6	1	100242	(NOT SHOWN) OPERATING MANUAL BG-38
7	1	100847	(NOT SHOWN) TAG H&S TOOL LOCKING
8	1	B002535	MOTOR ADAPTER
9	1	B004210	B DRIVESHAFT
10	1	CWL3468	AIR MOTOR
11	1	DCP2504	FTG QUICK COUPLER 3/8B x 1/2 NPTM MALE AIR
12	1	HS50509	(NOT SHOWN) ASSY 1/2" HOSE/IN-LINE OILER PRESSURE FEED
13	1	103120	(NOT SHOWN) ASSY SHIPPING CRATE BG38
14	1	B002529	GEAR BEVEL 9 TOOTH 10 PITCH 20 DEG FORM CUSTOM
15	1	94900	ASSY SHIPPING CRATE BF-R
16	1	98723	(NOT SHOWN) ASSY TOOLKIT BG


FIGURE A-4. BG38 BOILER GUN HIGH-VELOCITY PNEUMATIC ASSEMBLY (P/N BG38HV-R)



PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	11731	SCREW 5/16-18 X 1 SSSHDP
2	1	93084	MOTOR AIR MODIFIED CML3460 FOR BF-R
7	1	98855	SWIVEL DOUBLE AIR 1/2 NPTM X 1/2 NPTF
8	1	99969	NFIS BASE UNIT BG38 BOILER GUN TUBE BEVELER WRENCH FEED
5	1	98723	(NOT SHOWN) ASSY TOOLKIT BG
9	1	100207	(NOT SHOWN) LABEL BG38LV METALLIC
10	1	100242	(NOT SHOWN) OPERATING MANUAL BG-38
11	1	100847	(NOT SHOWN) TAG H&S TOOL LOCKING
14	1	B002531	MOTOR ADAPTER
15	1	DCP2504	FTG QUICK COUPLER 3/8B x 1/2 NPTM MALE AIR
16	1	HS50509	(NOT SHOWN) ASSY 1/2" HOSE/IN-LINE OILER PRESSURE FEED
12	1	103120	(NOT SHOWN) ASSY SHIPPING CRATE BG38
13	1	B002529	GEAR BEVEL 9 TOOTH 10 PITCH 20 DEG FORM CUSTOM
4	1	94902	KEY WOODRUFF MODIFIED 3/16 X .740
3	1	94900	ASSY SHIPPING CRATE BF-R
6	1	98723	(NOT SHOWN) ASSY TOOLKIT BG

FIGURE A-5. BG38 BOILER GUN LOW-VELOCITY PNEUMATIC ASSEMBLY (P/N BG38LV-R)


AVAILABLE CONFIGURATIONS		
PART NO.	DESCRIPTION	ITEM 14
BG38E110-R	MODEL BG38 BOILER GUN ELEC 110V 0.75KW WRENCH FEED	EB002615
BG38E220-R	MODEL BG38 BOILER GUN ELEC 220V 0.75KW WRENCH FEED	EOD005504
BG38C110-R	MODEL BG38 BOILER GUN CORDLESS ELEC 120V 1HP WRENCH FEED	103054
BG38C220-R	MODEL BG38 BOILER GUN CORDLESS ELEC 220V 0.75KW WRENCH FEED	103055



APPEARANCE OF ITEM WILL VARY


PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	911-0011	KEY 3/16 RADIUS ONE SIDE X 3/4 SQ BOTH ENDS
2	1	11118	SCREW 1/4-20 X 1 SHCS
3	1	15328	BRG NEEDLE 1-1/8 ID X 1-3/8 OD X .500 OPEN
4	1	94900	ASSY SHIPPING CRATE BF-R
5	1	98723	(NOT SHOWN) ASSY TOOLKIT BG
6	1	99969	NFIS BASE UNIT BG38 BOILER GUN TUBE BEVELER WRENCH FEED
7	1	100242	(NOT SHOWN) OPERATING MANUAL BG-38
8	1	100251	(NOT SHOWN) LABEL BG38EL METALLIC
9	1	100847	(NOT SHOWN) TAG H&S TOOL LOCKING
10	1	103120	(NOT SHOWN) ASSY SHIPPING CRATE BG38
11	1	105795	ADAPTER ELECTRIC MOTOR
12	1	B002529	GEAR BEVEL 9 TOOTH 10 PITCH 20 DEG FORM CUSTOM
13	1	EB002614	ELECTRIC DRIVE SHAFT
14	1	SEE TABLE	MOTOR DRIVE METABO

FIGURE A-6. BG38E110-R BOILER GUN ELECTRIC ASSEMBLY (P/N 102987)




PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	921-1001	SNAP RING 11/16 ID X .042 TH
2	6	923-1001	COTTER PIN 3/32" X 1/2"
3	1	B002520L	LG COLLET CENTERSHAFT
4	1	B002550L	LONG B COLLET ROD
5	1	BC58	ASSY B COLLET 5/8" 5 DEGREE
6	1	BC34	ASSY B COLLET 3/4" 5 DEGREE
7	1	BC78	ASSY B COLLET 7/8" 5 DEGREE
8	1	BC1	ASSY B COLLET 1" 5 DEGREE
9	1	BC1-18	ASSY B COLLET 1-1/8" 5 DEGREE
10	1	BC1-14	ASSY B COLLET 1-1/4" 5 DEGREE
11	1	BC1-38	ASSY B COLLET 1-3/8" 5 DEGREE
12	1	BC1-12	ASSY B COLLET 1-1/2" 5 DEGREE
13	1	BC1-58	ASSY B COLLET 1-5/8" 5 DEGREE
14	1	BC1-34	ASSY B COLLET 1-3/4" 5 DEGREE
15	1	BC1-78	ASSY B COLLET 1-7/8" 5 DEGREE
16	1	BC2	ASSY B COLLET 2" 5 DEGREE
17	1	BC2-14	ASSY B COLLET 2-1/4" 5 DEGREE
18	1	BC2-18	ASSY B COLLET 2-1/8" 5 DEGREE
19	1	BC2-38	ASSY B COLLET 2-3/8" 5 DEGREE
20	1	BC2-12	ASSY B COLLET 2-1/2" 5 DEGREE
21	1	BC2-58	ASSY B COLLET 2-5/8" 5 DEGREE
22	1	BC2-34	ASSY B COLLET 2-3/4" 5 DEGREE
23	1	BC2-78	ASSY B COLLET 2-7/8" 5 DEGREE


FIGURE A-7. BG38CP COLLET KIT ASSEMBLY (P/N 103077)



Item #	Part name	Part number	Item #	Part name	Part number
1	Wedge set B-01 (.625-.810")	100216	14	Wedge extension B-14 (2.250-2.435")	100229
2	Wedge set B-02 (.750-.935")	100217	15	Wedge extension B-15 (2.375-2.560")	100230
3	Wedge set B-03 (.875-1.060")	100218	16	Wedge extension B-16 (2.500-2.685")	100231
4	Wedge set B-04 (1.000-1.185")	100219	17	Wedge extension B-17 (2.625-2.810")	100232
5	Wedge set B-05 (1.125-1.310")	100220	18	Wedge extension B-18 (2.750-2.935")	100233
6	Wedge set B-06 (1.250-1.435")	100221	19	Wedge extension B-19 (2.875-3.060")	100234
7	Wedge set B-07 (1.375-1.560")	100222	20	3/32x3/16" Spring pin	100269
8	Wedge set B-08 (1.500-1.685")	100223	21	8-32x5/16" Socket head cap screw	100270
9	Wedge set B-09 (1.625-1.810")	100224	22	Wedge guide (B-01-B-05)	100213
10	Wedge set B-10 (1.750-1.935")	100225	23	Wedge band spring	100245
11	Wedge extension B-11 (1.875-2.060")	100226	24	Wedge guide (B-06 - B-14)	100214
12	Wedge extension B-12 (2.000-2.185")	100227	25	Wedge extension spring	100246
13	Wedge extension B-13 (2.125-2.310")	100228			




P/N 98231
SCALE 1 : 1



P/N 103083
SCALE 1 : 1


FIGURE A-8. BG38 TOOL HOLDER ASSEMBLY (P/N 103081)



P/N 103084
SCALE 1:1


PARTS LIST						
ITEM	QTY 103083	QTY 103084	QTY 98231	QTY BG38THS	P/N:	DESCRIPTION
1	3	2	2	7	000875	BLADE LOCK
2	6	4	4	10	917-0001	SCREW DIFFERENTIAL XNS-48
3	1	1	1	3	20812	RING O 3/32 X 5/8 ID X 13/16 OD
4	1	1	1	3	77253	SCREW 5/16-18 X 1/2 SSSFP
5	0	0	1	1	B002534	TOOLHOLDER SLIDING 2-5/8" 2-FLUTE
6	1	0	0	1	B002536	TOOLHOLDER SLIDING 2-5/8" 3-FLUTE
7	0	1	0	1	B002565	TOOLHOLDER SLIDING 3" 2-FLUTE

FIGURE A-9. BG38 TOOL HOLDER ASSEMBLY PARTS LIST (P/N 103081)




PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	11019	RING SNAP 5/8 OD X .035 THICK
2	1	100211	SPEED WHEEL, BG22-BG38
3	1	100215	WEDGE CENTER SHAFT 0.625 BG22-BG38
4	1	100216	SET WEDGE B-01 BG22 BG38 5/8" - 3/4"
5	1	100217	(NOT SHOWN) WEDGE SET B-02 BG22-BG38 3/4" - 7/8"
6	1	100218	(NOT SHOWN) WEDGE SET B-03 BG22-BG38 7/8" - 1"
7	1	100219	SET WEDGE B-04 1" - 1-1/8"
8	1	100220	(NOT SHOWN) WEDGE SET B-05 BG22-BG38 1-1/8" - 1-1/4"
9	1	100221	(NOT SHOWN) WEDGE SET B-06 BG22-BG38 1-1/4" - 1-3/8"
10	1	100222	(NOT SHOWN) WEDGE SET B-07 BG22-BG38 1-3/8" - 1-1/2"
11	1	100223	(NOT SHOWN) WEDGE SET B-08 BG22-BG38 1-1/2" - 1-5/8"
12	1	100224	(NOT SHOWN) WEDGE SET B-09 BG22-BG38 1-5/8" - 1-3/4"
13	1	100225	(NOT SHOWN) WEDGE SET B-10 BG22-BG38 1-3/4" - 1-7/8"
14	1	100226	SET WEDGE EXT B-11 BG22 BG38 1-7/8" - 2"
15	1	100227	(NOT SHOWN) SET WEDGE EXT B-12 BG22-BG38 2" - 2-1/8"
16	1	100228	(NOT SHOWN) SET WEDGE EXT B-13 BG22-BG38 2-1/8" - 2-1/4"
17	1	100229	(NOT SHOWN) SET WEDGE EXT B-14 BG22-BG38 2-1/4" - 2-3/8"
18	1	100230	(NOT SHOWN) SET WEDGE EXT B-15 BG22-BG38 2-1/2" - 2-5/8"
24	1	100240	(NOT SHOWN) LABEL WEDGE CHART BG22/BG38
19	1	100231	(NOT SHOWN) SET WEDGE EXT B-16 BG22-BG38 2-5/8" - 2-3/4"
20	1	100232	(NOT SHOWN) SET WEDGE EXT B-17 BG22-BG38 2-3/4" - 2-7/8"
21	1	100233	(NOT SHOWN) SET WEDGE EXT B-18 BG22-BG38 2-7/8" - 3"
22	1	100234	(NOT SHOWN) SET WEDGE EXT B-19 BG22-BG38 3" - 3 1/8"
25	1	100278	ASSY WEDGE ROD 0.625 BG22 BG38
26	1	100279	ASSY WEDGE ROD 1.000 BG22 BG38

FIGURE A-10. WEDGE MOUNT SYSTEM KIT (P/N 103081)



PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	19297	FTG QUICK COUPLER 3/8B 1/2 NPTF FEMALE AIR
2	1	95056	LABEL ROUND 3/4" OIL FLUID
3	1	95087	LABEL ROUND 3/4" FILTER
4	1	2152030	ASSY HOSE 7094 1/2 ID X 1/2 NPTM X 1/2 NPTM X 72"
5	1	HS50512	LUBRICATOR INLINE 1/2 NPTF X 1/2 NPTF
6	1	HS50517	FTG NIPPLE CLOSE 1/2 NPTM SCH 40
7	1	HS50518	SCREEN INLINE 40 MICRON 1/2 NPTF X 1/2 NPTF
8	1	HS50524	FTG COUPLER 1/2 NPTM X CHICAGO W/ SAFETY PIN & LANYARD

FIGURE A-11. AIR HOSE ASSEMBLY (P/N HS50509)



INSIDE OF CASE

PARTS LIST			
ITEM	QTY	P/N:	DESCRIPTION
1	1	911-0005	KEY 3/16 RADIUS ONE SIDE X 5/8 SQ BOTH ENDS
2	4	921-1001	SNAP RING 11/16 ID X .042 TH
3	2	923-1001	COTTER PIN 3/32" X 1/2"
4	4	10534	RING SNAP 1 OD
5	4	11206	SCREW 5/16-18 X 5/16 SSSCP
6	2	19729	NUT 5/16-18 NYLON INSERT LOCKNUT
7	3	29377	SCREW 8-32 X 5/16 SHCS
8	6	100246	SPRING EXT 0.125 OD X .020 WIRE X 2.125 LONG ZINC
9	6	100578	SPRING EXT .125 OD X .018 WIRE X 1.875 ZINC
10	1	AWTORX	WRENCH HEX/TORX SET 1/8, 9/64, 5/32, T9, T15 H&S LOGO
11	1	SNAP	PLIER SNAP RING FLAT TIPPED 11/16 - 7/8
12	1	TK	CASE COMPARTMENT 8 X 4-1/8 X 1-3/16

FIGURE A-12. TOOL KIT (P/N 100603)

APPENDIX B SDS

Contact CLIMAX for the latest Safety Data Sheets.

This page intentionally left blank

 **CLIMAX**

 **BORTECH**  **CALDER** **H&S** **TOOL**